

INDIANA STATE DEPARTMENT OF HEALTH

Telephone: 317/233-7360 FAX: 317/233-7334

Individual Submitting Request: Date: 3 / 23 / 2009 Name: Ryan Edwards Telephone: (502) 876-1440 Email: ryanedwards@live.com Mailing Address: 405 Sunnyside dr Number & Street IN 47150 New Albany P.O. Box 2. Person/Organization Seeking Variance: Name: HoosierIceMan LLC Email: ryanedwards@live.com Mailing Address: 405 Sunnyside Dr New Albany IN 47150 P.O. Box 3. Food Establishment(s) for Which Variance is Sought Include the following information for each food establishment: (List here or attach additional pages if necessary) Physical Location (If different than mailing address): 1049 Market St Charlestown, IN 47111 Mailing Address: 405 Sunnyside dr New Albany IN 47150 (Number, Street, City, State, & Zip Code) Telephone Number: (502) 876-1440 Fax Number: (Person at each retail food establishment most responsible for supervising: Ryan Edwards 4. State how the proposal varies from each rule requirement, citing relevant rule sections by number: (Attach additional pages if necessary) 410IAC 7-24-375 states that all permanent structures in Indiana must have sewers attached for disposal of wastewater. Request a variance that an Ice House Americas Ice Hut should not be deemed a permanent structure as the unit will be secured to the ground(using cables) but does not have a concrete slab or sub structure. Therefore a sewer connection would not be required. Or be allowed a variance allowing a holding tank to be used to store the small amount (1 gallon a month) of cleaning solution. 5. Explain how the potential public health hazards and/or nuisances will be alternatively addressed by the proposal. Include supporting studies, Hazard Analysis Critical Control Point (HACCP) Plan(s), standard sanitation operating procedures, and/or any other evidence: (Attach additional pages, if necessary.) Attached you will find the state approved designed documents for the Ice House Americas Ice Hut. In the document a holding tank can be used to collect a small amount of cleaning solution for the monthly cleaning process. During the rest of the month the holding tank is not attached as the only runoff is condensation from the refrigeration process. The cleaning process does create 1 gallon of a sanitation solution which would need to be disposed of properly offsite. Also attached is the cleaning manual for reference. **6.** List how the proposal demonstrates the following (if applicable to the request): A) How the proposal differs from what is common and usual in similar industry situations: Monthly or quarterly sanitation procedure does not produce the same amount of wastewater as other food service operations. We

produce 1 gallon of wastewater a month. The statue was written for much higher volumes of wastewater and could not anticipate this kind of unit being developed.

B) How the proposal is unique and not addressed in existing rules or law: The proposal is unique in that the state code does not identify or handle Ice Manufacturing structures

RECEIVED

C) How the proposal does not diminish the protection of public health: The holding tank is used temporally to gather a sanitation solution during the monthly cleaning processing is completed it will be immediately disposed of without any chance to containment any cactual Ice Hut outside of the cleaning process does not create any toxic or harmful chemicals that consumption of ice. The unit never comes in contact with human skin and a state approved sanitize much cleaner than the current industry standard of holding ice in bins outside of gas stations. D) How the proposal is based on new scientific or technological principle(s): Not based on new stantdards just proper use of commonly accepted pratices.	of the surrounding ground. The would affect human
E) How the implementation of the variance would be practical: The implementation of the variance would be practical because only a small amount of waste che basis(1 gallon). Under the proposed scenario all waste would be disposed of properly without ha	
7. Explain how the person/organization seeking the variance will assure that all prevariance will be enacted at each food establishment for which a variance has be Each Ice Hut is an unoccupied structure. To ensure proper handling of the variance requested and general, will be the owner's responsibility. At the time of cleaning care would need to be taken we solution that enters the holding tank.	en granted: I the food protection code in
8. List all affected parties known by the person/organization seeking a variance, in regulatory authorities: (Attach additional pages if necessary) George Jones - Indiana State Department of Health Laura Lindley - Clark County Health Department Hank Wolf - Clark County Health Department Scott Gilliam- Indiana State Department of Health	ncluding all affected
9. Attach copies of any related variances, waivers or opinions issued by other governmental agencies.	For Office Use Only
10. Signature of Individual Making Request: //yw Sw FdwV	
Printed Name, Title: Ryan Edwards President HoosierleeMan, LLC	

RECEIVED

MAR 25 2009

FOOD PROTECTION PROGRAM INDIANA STATE DEPT. OF HEALTH



Section III Standard Sanitation & Maintenance Operating Procedure (SSOP) Table of Contents

Introduction	Page 2
Sanitation Standard Issue Materials	Page 2
Chemical & Tool Storage	Page 3
Bag Storage	Page 3
Operating Instructions	Page 3
Written Records	Page 3
Floor Cleaning Procedure	Page 3
Weekly Cleaning Procedure	Page 4
Monthly/Quarterly Cleaning Procedure	Page 5
Ice Maker Cleaning Procedure	Page 7
Ice Bin Sanitization Procedure	Page 9
Incline Auger Sanitization Procedure	Page 10
Water Dispenser Sanitization Procedure	Page 12
Municipal Boil Order Shutdown Procedure	Page 13
Bloodborne Pathogens Decontamination Procedure	Page 14
Identification of Origin	Page 14
Labeling Requirements	Page 14

INTRODUCTION

Congratulations on your purchase of an Ice House America ice vending machine. At Ice House America we are dedicated to providing customers with a quality ice product that is both safe and clean. Our ice vending machines are made from only the highest quality materials, from the stainless steel surfaces and components, to the food grade materials found throughout the construction of our ice production and vending product. We designed our ice vending machines so that the product would have minimal exposure to any possible outside contamination sources.

Before our ice vending machines leave the manufacturing facility, our crews thoroughly clean and sanitize your ice vending machine. Once on site the machine will again be cleaned and sanitized by the setup crew before any product is produced.

As a responsible owner you will be accountable for implementing a regular cleaning and maintenance schedule as outlined below. By following these Standard Sanitation and Operating Procedures (S.S.O.P) you can be assured that your ice vending machine will stay clean and continue to produce a quality product in which your customers can feel confident.

IHA reserves the right to notify the applicable state agencies and take additional action as appropriate should proper sanitation and operating procedures not be maintained.

SANITATION STANDARD ISSUE MATERIALS

To assist ice vending machine owners with sanitation, the following materials come standard with each ice vending machine: sanitizer applicator assembly, chlorine test kit, sanitizer, coiled water hose, glove dispenser with one box of gloves, H.B. 30 ice machine cleaner, and sink (optional except where required by Government Regulations such as in Florida). These materials, as well as Sani-System sanitizer, can be purchased from Ice House America:

Ice House America 278 US Highway 319 S Moultrie, GA 31768 229-890-7000

CHEMICAL & TOOL STORAGE

It is suggested that chemicals and hand tools used in the maintenance and cleaning of each ice vending machine be kept either in the service vehicle, in a sealed storage container or cabinet inside the ice vending machine itself (in models M-101/M-101N¹ and M-102/M-102N¹ only, at least 6 inches from the floor), or in a separate storage shed. This is important in order to avoid contamination from accidental spills. This applies to all cleaning items, lubricants and other maintenance material, and ice shovels if used. All items should be clearly labeled for identification. Chemicals and hand tools may not be stored in model M-103/M-103N² ice vending huts since there is no room separate from the ice storage area.

BAG STORAGE

A supply of packaging bags may be stored inside the ice vending machine at least 6 inches off the floor. All remaining bags must be stored in an approved facility. This facility may be a commissary, climate controlled storage unit or a specially built storage shed that is vermin proof and made of materials that can be cleaned easily and approved for the storage of food grade packaging materials.

OPERATING INSTRUCTIONS

The SSOPs are the manufacturer's specification on cleaning and maintaining the ice vending machine. A copy must be kept in each ice vending machine for reference.

WRITTEN RECORDS

A maintenance and cleaning log should be displayed within the ice vending machine. The log should contain a written record of weekly, monthly and quarterly maintenance and sanitation activity. A copy of any reports from 3rd parties relating to safety and compliance of operations should be placed in the log. (For samples, see Exhibit "A")

FLOOR CLEANING PROCEDURE

A. FREQUENCY

The floor should be cleaned any time ice vending machine is entered.

- 1. Remove any dirt or mud tracked on the floors of the front interior chamber with a damp sponge. It is suggested that a towel be placed on the floor of the ice vending machine before entering.
- 2. Spray the floor with non-rinse sanitizer mixture. Allow to air dry for two minutes and then wipe with a clean terry cloth.

¹ Models M-101(N) and M-102(N) refer to the original sized ice vending machines.

² Model M-103(N) refers to the smaller ice vending hut.

WEEKLY CLEANING PROCEDURE

A. MATERIALS NEEDED

- 1. Handheld Spray Bottle
- 2. Hand Sanitizer
- 3. Single-use Latex Gloves
- 4. Clean Terry Cloth (or equivalent)
- 5. Non-rinse Sanitizer (unscented bleach)
- 6. Chlorine Test Kit
- 7. Stainless Steel Cleaner

- 1. Prepare a mixture of water and unscented bleach (1/2 oz to 1 gallon should yield a mixture between 50 and 200 ppm). Test the concentration of the mixture with a test strip from the test kit. Do not mix more than is needed for the day's use, as the mixture becomes less effective over time.
- 2. Spray all exterior surfaces that are regularly touched during customer use with the prepared and tested sanitizer mixture in a spray bottle. This includes the selection controls and all stainless steel face plates and product distribution surfaces, including water dispensing nozzle (if equipped). All surfaces not in contact with ice or water should be allowed to air dry for two minutes and then wiped with a clean terry cloth. All surfaces in contact with ice and water must be allowed to air dry only, in order to avoid recontamination of surfaces.
- 3. Spray exterior stainless steel surfaces that are not in contact with ice or water with a stainless steel cleaner to keep surface looking clean and shining.
- 4. Pick up all trash and dispose of it properly.
- 5. Remove any dirt or mud tracked on the floors of the front interior chamber with a damp sponge. It is suggested that a towel be placed on the floor of the ice vending machine before entering.
- 6. Spray the floor with prepared sanitizer mixture. Allow to air dry for two minutes and then wipe with a clean terry cloth.
- 7. Note completion of weekly cleaning in maintenance and cleaning log.

MONTHLY/QUARTERLY CLEANING PROCEDURE

A. MATERIALS NEEDED

- 1. Handheld Spray Bottle
- 2. Hand Sanitizer
- 3. Single-use Latex Gloves.
- 4. Clean Terry Cloth (or equivalent)
- 5. Non-rinse Sanitizer (unscented bleach).
- 6. Chlorine Test Kit.
- 7. Stainless Steel Cleaner

- 1. Prepare a mixture of water and unscented bleach (1/2 oz to 1 gallon should yield a mixture between 50 and 200ppm). Test the concentration of the mixture with a test strip from the test kit. Do not mix more than is needed for the day's use, as the mixture becomes less effective over time.
- 2. Spray all exterior surfaces that are regularly touched during customer use with the prepared and tested sanitizer mixture in a spray bottle. This includes the selection controls and all stainless steel face plates and product distribution surfaces, including water dispensing nozzle (if equipped). All surfaces not in contact with ice or water should be allowed to air dry for two minutes and then wiped with a clean terry cloth. All surfaces in contact with ice and water must be allowed to air dry only, in order to avoid recontamination of surfaces.
- 3. Spray exterior stainless steel surfaces that are not in contact with ice or water with a stainless steel cleaner to keep surface looking clean and shining.
- 4. Lift lid on transition box.
- 5. De-energize bin floor motor (pull safety switch).
- 6. Remove ice from transition box by activating incline auger contactor until ice is removed.
- 7. De-energize incline auger and rake motors (pull safety switches).
- 8. Wash hands, sanitize them with non-rinse hand sanitizer, and put on gloves.
- Spray transition box with the prepared sanitizer mixture in hand sprayer, making sure sanitizer covers ends of augers and complete box. Allow to air dry.

- 10. Spray exit end of incline auger with the prepared sanitizer mixture in hand sprayer, covering entire auger from top to bottom. Allow to air dry.
- 11. Spray chute assemblies, including dump boxes, with the prepared sanitizer mixture. Allow to air dry.
- 12. Re-energize bin floor, incline auger, and rake motors (push in safety switches).
- 13. Vend 3 bag vends and 3 bulk vends, if equipped, to insure proper operation once parts have been allowed to air dry for two minutes or adequately drain.
- 14. Wipe down all interior stainless equipment not in contact with ice or water with prepared sanitizer mixture and a clean terry cloth. Allow to air dry for two minutes.
- 15. Clean ice maker (see ice maker cleaning procedure below).
- 16. Clean UV disinfection system if ice vending machine is equipped with a water dispenser (see Sterilight owner's manual).
- 17. Pick up all trash and dispose of it properly.
- 18. Remove any dirt or mud tracked on the floors of the front interior chamber with a damp sponge. It is suggested that a towel be placed on the floor of the ice vending machine before entering.
- 19. Spray the floor with prepared sanitizer mixture. Allow to air dry for two minutes and then wipe with a clean terry cloth.
- 20. Note completion of monthly cleaning in maintenance and cleaning log.
- 21. A quarterly coaliform test should be done of the finished product (ice) using a local lab facility. Results should be posted in the control room of the ice machine. See Exhibit "C."
- 22. Monthly or quarterly pest control spray of the perimeter is necessary. It is recommended that a professional pest control service be used. If spraying is done in ice vending machine, make sure that equipment and procedure are done in accordance with pest control safety strategy. After any application of insecticides or pesticides inside ice vending machine, all stored ice must be discarded and the monthly cleaning procedure completed.

ICE MAKER CLEANING PROCEDURE

A. FREQUENCY

The ice maker should be cleaned as part of the monthly/quarterly cleaning procedure (above). While monthly/quarterly is suggested, the actual cleaning schedule may vary depending upon the condition of the water (i.e. use of a water softener may reduce amount of deposits that form).

B. MATERIALS NEEDED

- 1. H.B. 30 Ice Machine Cleaner (or acceptable substitute)
- 2. Sani-System Liquid Sanitizer Concentrate (one bag 1/2 oz)

- 1. Prepare a method of capturing ice maker drainage (drain plumbed to holding tank, container placed under drain, etc.). Drainage from this procedure should be captured and disposed of properly.
- 2. Cut off ice maker by switching ice maker toggle switch to the OFF position immediately after harvest.
- 3. Remove any unharvested ice from ice maker (not the ice bin) to avoid contamination.
- 4. Shut off water supply and drain sump tank.
- 5. Remove any accumulated particles and excessive lime deposits.
- 6. Close drain and fill sump with water. Warm water may expedite the cleaning process.
- 7. Add H.B. 30 ice machine cleaner (10 20 oz), or an acceptable substitute (in accordance with its instructions).
- 8. Circulate cleaning solution by switching toggle switch to the PUMP position (down). Allow solution to circulate for thirty minutes (or until deposits are dissolved).
- 9. Stop circulation by switching toggle switch to the OFF position.
- 10. Drain and flush water sump.
- 11. Replace water drain cap and allow float valve to fill sump. Switch toggle switch to the PUMP position (down) and allow fresh water to flush water distributors.
- 12. Repeat steps 10 and 11 to ensure that the cleaning agent has been flushed from entire water system.

- 13. Replace water drain cap and allow float valve to fill sump.
- 14. Open and dispense one (1) bag of Sani-System liquid sanitizer concentrate into sump.
- 15. Circulate sanitizer by switching toggle switch to the PUMP position (down). Allow sanitizer to circulate for three minutes.
- 16. Stop circulation by switching toggle switch to the OFF position.
- 17. Allow 60 sec. of contact time.
- 18. Drain and flush water sump.
- 19. Replace water drain cap and allow float valve to fill sump. Switch toggle switch to the PUMP position (down) and allow fresh water to flush water distributors.
- 20. Repeat steps 18 and 19 to ensure that the sanitizer has been flushed from entire water system.
- 21. Clean inside of ice bin and remove any solution that may have entered during cleaning process. Remove cover, if installed, over opening into the storage area.
- 22. Sanitize ice bin by following the Ice Bin Sanitization Procedure.
- 23. Dispose of drainage captured from ice maker properly. Take container to a toilet or sink and empty contents into a city sewer system. Make sure that none of the contents come in contact with the environment.
- 24. Resume ice vending machine operation.

ICE BIN SANITIZATION PROCEDURE

A. FREQUENCY

The ice bin should be cleaned before start-up operations begin. If remedying a mechanical failure involves human contact with or contact between unsanitized tools and the ice bin, the ice bin should be emptied of ice and sanitized. If the water source should become polluted, the ice bin should be emptied of ice and sanitized. It is also recommended, as a precautionary measure, that if the ice bin is emptied due to high sales, the ice bin should be sanitized before making more ice.

B. MATERIALS NEEDED

- 1. Hand Sanitizer
- 2. Single-use Latex Gloves
- 3. Non-rinse Sanitizer (unscented bleach)
- 4. Sanitizer Applicator Assembly (sprayer lid assembly, sanitizer container, spray gun for attachment to water hose, provided in sanitation kit)
- 5. Flexible Water Hose

- 1. If using the holding tank method of discharge collection:
 - a. Turn valve in waste disposal system to "Off" position.
 - b. Connect holding tank to discharge pipe for collection.
- 2. Add undiluted, unscented bleach to sanitizer applicator container. Attach container to sprayer lid assembly, making sure dilution metering tip is in place. Attach spray gun to water hose. Attach applicator assembly to female quick connect on spray gun.
- 3. Test sanitizing solution with sanitizer test kit to insure proper concentration of between 50 ppm and 200 ppm.
- 4. Wash hands, sanitize them with non-rinse hand sanitizer, and put on gloves.
- 5. Use sanitizer applicator assembly to apply sanitizer to the entire bin and horizontal auger surface, including auger blade. Bleach is a non-rinse sanitizer; simply close bin door after application.
- 6. If using the holding tank method of discharge collection;
 - a. Disconnect holding tank from discharge pipe
 - b. Reconnect pipe to French drain
 - c. Turn valve to "on" position
 - d. Take holding tank to a toilet or sink and empty contents into a city sewer system.

INCLINE AUGER SANITIZATION PROCEDURE

A. MATERIALS NEEDED

- 1. Hand Sanitizer
- 2. Single-use Latex Gloves.
- 3. Non-rinse Sanitizer (unscented bleach).
- 4. Chlorine Test Kit.
- 5. Sanitizer Applicator Assembly (sprayer lid assembly, sanitizer container, spray gun for attachment to water hose, provided in sanitation kit)
- 6. Flexible Water Hose
- 7. Ice Capture Container (ex: 32 gallon trash can)

- 1. Add undiluted, unscented bleach to sanitizer applicator container. Attach container to sprayer lid assembly, making sure dilution metering tip is in place. Attach spray gun to water hose. Attach applicator assembly to female quick connect on spray gun.
- 2. Test sanitizing solution with a test strip to insure proper concentration of between 50 and 200ppm.
- 3. Place ice capture container under bulk chute, if equipped. Ice used in this procedure should be captured and disposed of properly.
- 4. Remove ice bin front shield for easier access to horizontal auger. CAUTION SHOULD BE TAKEN AROUND THE MOVING PARTS OF THE RAKE, BIN FLOOR, AND AUGERS WHILE FRONT SHIELD IS REMOVED.
- 5. Lift lid on transition box.
- 6. Wash hands, sanitize them with non-rinse hand sanitizer, and put on gloves.
- 7. Fill horizontal auger with ice from one end to the other, completely covering auger flighting.
- 8. De-energize bin floor motor (pull safety switch). This will prevent fresh ice from falling into horizontal auger.
- 9. Spray ice occupying horizontal auger and transition box with sanitizer applicator assembly until ice is thoroughly coated (approximately two minutes).
- 10. Continue to spray ice entering incline auger with sanitizer while activating incline auger contactor, if equipped with bulk, or vending bags until nearly all ice in horizontal auger and transition box is removed. The auger will carry

sanitizer-coated ice through the auger tube, sanitizing the auger and tube. Avoid spraying orange proximity switch in transition box as doing so may cause the horizontal auger to shut off and quit supplying ice to the transition box.

- 11. Allow 60 sec. of contact time between sanitizer-coated ice and the auger.
- 12. De-energize incline auger (pull safety switch).
- 13. Test exit end of incline auger with a test strip. Concentration should be between 50 and 200ppm. Repeat steps 7 13 if needed.
- 14. Re-energize incline auger and bin floor motors (push in safety switches).
- 15. Activate incline auger contactor for at least two minutes, if equipped with bulk, or vend 15 bags to remove sanitizer from auger.
- 16. De-energize incline auger, rake, and bin floor motors (pull safety switches).
- 17. Test exit end of incline auger with a test strip for absence of sanitizer.

 Concentration should be less than 50ppm. Repeat steps 14 17 if sanitizer is still present.
- 18. Replace ice bin front shield.
- 19. Re-energize incline auger, rake, and bin floor motors (push in safety switches).
- 20. Dispose of ice captured in ice capture container properly. Take container to a toilet or sink and empty contents into a city sewer system. Make sure that none of the contents come in contact with the environment.

WATER DISPENSER SANITIZATION PROCEDURE

A. FREQUENCY

The water dispenser, if equipped, should be sanitized before start-up operations begin, after any repair to the dispenser, at every filter change, and if the water source should become polluted for any reason (water advisory, for instance).

B. MATERIALS NEEDED

- 1. Sani-System Liquid Sanitizer Concentrate (three bags 1/2 oz each)
- 2. Replacement Sediment Filter Cartridge
- 3. Replacement De-chlorinator Cartridge

- 1. Ensure UV unit and lamp are on and operational during entire process.
- 2. Turn off valve to filter. Relieve line pressure on filter housing by dispensing one (1) gallon of water.
- 3. Ensure hard water bypass valve is turned off. Also, ensure valve from water softener is turned on.
- 4. Remove de-chlorinator cartridge from its housing. Replace housing.
- 5. Remove sediment filter cartridge from its housing.
- 6. Open and dispense three (3) bags of Sani-System liquid sanitizer concentrate into sediment filter housing. Replace housing.
- 7. Turn on valve to filter.
- 8. Dispense ten (10) gallons of water through water dispenser to circulate sanitizer. Discard water,
- 9. Allow a minimum of 60 seconds contact with water dispenser system.
- 10. Flush dispensing system with twenty (20) gallons of water through water dispenser. Discard water.
- 11. Turn off valve to filter. Relieve line pressure on filter housing by dispensing one (1) gallon of water.
- 12. Remove sediment filter housing. Discard remaining water in housing. Install new sediment filter cartridge. Replace housing.
- 13. Remove de-chlorinator housing. Discard remaining water in housing. Install new de-chlorinator cartridge. Replace housing.
- 14. Turn on valve to filter.

MUNICIPAL BOIL ORDER SHUTDOWN PROCEDURE

A. EMERGENCY RESPONSE FOR FLOODS OR OTHER SOURCES OF CONTAMINATION

In the event that the local government or water authority issues an emergency boil order due to flood or other source of contamination the following procedure will apply.

- 1. Stop use of the ice vending machine immediately.
- 2. The ice vending machine should be emptied, cleaned and sanitized before returning it to production.

B. PROCEDURES FOR CLEANING AND SANITIZING. SPECIAL REQUIREMENTS IN THE EVENT OF AN EMERGENCY BOIL ORDER DUE TO CONTAMINATION OF THE WATER SOURCE.

- 1. Determine if existing water supply is safe.
 - a. Public Water Supply- contact the water company.
 - b. Private well- determine if the well has been covered by flood water, or if flood waters have been nearby. If so, the well could be contaminated. Contact your local Health Department or environmental health agency for information on well disinfection.
- 2. If water supply is contaminated or subject to a "boil" order, then:
 - a. Disconnect ice vending machine from electrical power.
 - b. Melt any stored ice.
 - c. Drain water from ice vending machine.
 - d. Do not initiate cleaning and sanitizing procedures (2) until water supply is safe.
- 3. Once water has been declared safe:
 - a. Clean ice maker (see ice maker cleaning procedure above).
 - b. Run ice maker through 2 or 3 freezing cycles or flush water supply line.
 - c. Turn off water supply.
 - d. Drain water from ice vending machine.
 - e. Circulate a cleaning solution of warm soapy water for two minutes; drain system.
 - f. Circulate clean water rinse for two minutes; drain system.
 - g. Spray ice bin surface with sanitizer solution following procedures described above.
 - h. Drain the system.
 - I. Repeat (g.).
 - j. Return the drain valves to their normal operating positions and restart system.

BLOODBORNE PATHOGENS DECONTAMINATION PROCEDURE

Emergency Response For Blood Spills:

Bloodborne pathogens are pathogenic microorganisms that are present in human blood and can cause disease in humans. These pathogens include, but are not limited to, hepatitis B virus (HBV), hepatitis C virus, and human immunodeficiency virus (HIV). Decontamination for surfaces contaminated with blood should be as follows:

- Surfaces contaminated with blood should be cleaned using a freshly prepared dilution of chlorine bleach solution.
- The contaminated area should be flooded with the bleach solution and then cleaned up using paper towels. Ten minutes of exposure is required for disinfection.
- Gloves should be worn during the clean-up procedures.

If blood should contaminate the produce stream, the following should be done:


• If blood is in the ice bin, the ice bin should be emptied and decontamination throughout the total product path and adjoining areas should be done.

IDENTIFICATION OF ORIGIN

In the event contamination occurs, it is advisable each ice vending machine owned be uniquely identified by number or address. This identification should be clearly displayed on the bag so that the source of contamination can be traced to the ice vending machine responsible. Although this is not a requirement by law, failure to identify the origin in this manner may result in a shut down of all unidentifiable ice vending machines until the source of contamination can be found. An owner of more than one ice vending machine can do this by having a separate set plate made for each ice vending machine purchased if they so desire.

LABELING REQUIREMENTS

At the very least the bags used must clearly display the name and contact information of the owner or ice vending machine operator. The label must also clearly indicate the weight of the product contained and any other labeling requirements as required by Title 21 Code of Federal Regulation, Part 101. The weight must be verified by a representative from the Bureau of Weights and Measures before initial start-up period.



Section III Exhibits Table of Contents

Monthly Maintenance Check List	Page .	A1
Finished Product Test Log	Page :	В1
Quarterly Water Test Log	. Pa	ıge

EXHIBIT "A"

MONTHLY PREVENTATIVE MAINTENANCE CHECKLIST (PLACE INITIAL INSIDE BOX INDICATING SERVICE PERFORMED)

Month of							
	MON	TUES	WED	THURS	FRI	SAT	SUN
	IVIOIN	1053	WED	Inuna	FBI	SAI	3014
Outside Appearance							
Light bulb operating in control panel/panel is dry							
Check air compressor purge water/sight glass							
Check blower							
Clean lens bill validator							
Danger! Before checking bin assembly turn bin floor, rake & screw OFF							
Remove & replace safety cover							
Check cross Auger - amount of Ice	,						
Check Transition box Door/Switch							
Chains							
Evaporator fans							
Ice maker level switch							
General check							
Monthly ice maker cleaning							<u> </u>
Notes:							

WEEKLY CLEANING & PREVENTATIVE MAINTENANCE LOG (PLACE INITIAL INSIDE BOX INDICATING SERVICE PERFORMED)

Week of	 		

	MON	TUES	WED	THURS	FRI	SAT	SUN
Outside Grounds							
Front Control Box Cleaned & Sanitized	 						
Adequate Lighting Inside/Outside							
Temperature OK							
Check Twist Ties							
Check Bags							
Check Dump Boxes/Bagging Unit							
Trash/Debris Removed							
Paper Towels							
Sanitizer							
All Items in Place							
Floors Cleaned & Sanitized							
General Appearance Acceptable				***************************************			
Drain Water From Air Tank On Compressor							
Check For And Remove Any Lubricants From Air Lines or Valves (This Will Avoid Warranties If The Equipment Is Not Properly Maintained)							
Lights on in PLC							
Notes:	,						

EXHIBIT "B"

FINISHED PRODUCT TEST LOG

Date	Time	Technician	Results	Next Test Date

		,		
	·····			

EXHIBIT "C"

QUARTERLY WATER TEST LOG (COALIFORM TESTING)

Supplies Needed:

Small Cooler Vials (2 per site) Testing Paperwork (1 form per site)

Steps:

Fill small cooler ½ way with ice to keep vials in once ice has been taken.

Reminder: TURN OFF RAKE & BIN FLOOR BEFORE GETTING THE ICE!

Fill testing vials with ice from bin and seal tightly.

Take to the local laboratory: each facility has their own method of accepting materials. Call ahead to find out procedure.

Test results will be mailed to you upon completion – enter results into Owner's Manual (see Exhibit "B") and post inside the ice vending machine.

Cost:

Coaliform testing can range from \$25.00 to \$50.00 per test.

GENERAL NOTES: (MIN. REQUIREMENTS)

STATE BUILDING CODE: 2008 INDIANA BUILDING CODE (2006 IBC WITH INDIANA AMENDS)

- ALL DOORS ARE OFFMABLE FROM THE EGRESS SIDE MITHOUT THE USE OF A KEY, TOOL, OF SECOLE KNOWLEDGE OR EFFORT: MANUALLY OFFRATED PUSH BOLTS OR SURFACE BOLTS SHALL NOT BE USED.
- CONSTRUCTION TYPE IS V-B.
- 3. THE STING OF THIS BUILDING IS THE RESPONSIBILITY OF THE BUILDING USER.
- 4. SEISMIC DESIGN CATEGORY-C
- 5. DESIGN SPEED IS 150 MPH, EXPOSURE C.
- 6. ONE STORY, 82.2 SC FT
- 7. OCCUPANCY CLASSIFICATION: S-2 ICE STORAGE BUILDING
- E. ROOF LIVE LOAD 50 PSF (SNOW CONTROLS), FLOOR UVE LOAD 125 PSF
- 9. PORTABLE FIRE EXTINGUISHERS SHALL BE PROVIDED BY OTHERS AS REQUIRED BY NFPA 10.

ELECTRICAL NOTES: (MIN. REQUIREMENTS)
2008 INDIANA ELECTRICAL CODE (2005 NEC WITH INDIANA AMENDS)

- ALL DROUTS AND EQUARIEST IS GROUNDED IN ACCORDANCE WITH THE APPROPRIATE APPROLES OF THE ANADOMAL ELECTRICAL CODE, IT SHALL BE THE RESPONSIBILITY OF THE BULDING INSTALLER TO PROPERTY OF DEVICE.

 INSTALLED ELECTRICAL EQUIPMENT OR DEVICE.
- PRIOR TO ENERGZING THE ELECTRICAL SYSTEM THE INTERPUTING PATING OF THE MAIN BREAKER MUST BE DESIGNED AND VERIFIED AS BEING IN COMPLETE COMPLIANCE WITH SECTION 110-9 OF THE NEC BY LOCAL ELECTRICAL CONSULTANT.
- ALL CECUTES AND ELECTRICAL EQUIPMENT SHALL BE GROUNDED IN ACCORDANCE WITH APPROPRIATE ARTICLES OF THE NATIONAL ELECTRICAL CODE.

MECHANICAL/PLUMBING NOTES:

2. MECHANICAL DESCR. EQUIPMENT & INSTALLATION TO CONFIDENT TO THE 2005 INDIANA MECHANICAL CODE (2006 INC WITH INDIANA AMENDS) PLUMBING DESSON, FABRICATION & INSTALLATION TO CONFORM TO THE 1989 INDIANA PLUMBING CODE (1887 UPC WITH INDIANA AMENDS

SITE INSTALLED ITEMS


COTE UST OF MEDESSARY ITEMS OF WERK AND MATERIALS, THAT MAY BE REQUIRED FOR COMPLETE INSTALLATIONS ARE THE RESPONSIBILITY OF DIMER, ALL SITE RELATION ITEMS ARE SUBJECT TO COMPLETE INSTALLATIONS ALL SITE RELATION ITEMS ARE SUBJECT TO COMPLETE INSTALLATIONS ALL SITE RELATION ITEMS ARE SUBJECT TO COMPLETE INSTALLATIONS OF THE PROPERTY OF THE PROPERTY

- COMPLETE FOUNDATION SUPPORT &
- IRS, & GENERAL ACCESS TO
- SERVICE HOOK-UP TO BUILDING.
- ICE MAKER MUST BE MOUNTED IN A MANNER THAT WILL ALLOW THE END WALL TO SHARE THE VERTICAL LOAD WITH THE REAR ICE BIN COLUMN, THE APPROVED DESIGN IS FOR ONLY ONE ROOF TOP MOUNTED ICE MAKER.

FOUNDATION:

THESE BUILDING PLAYS CONTAIN PREDMINARY
FOUNDATION SUPPORT AND IN DOWN SYSTEM
BUTALLS AND SPECIFICATIONS. THE ARCHITECT/ENGINEER
OF THE BUILDING PLAYS SHOULD BE CONTACTED TO DETAIN
SITE SPECIFIC FOUNDATION PLANS IF REQUIRED.

"HE FOUNDATION PLANS ARE DESIGNED BY OTHERS, HE ARCHITECT/BYGNEERS OF THE BUILDING PLANS HE ARCHITECT/BYGNEER OF CHELL FOR HE FOUNDATION DESIGNS AND THE CONSEQUENTIAL ERFORMANCE OF THE SUPERSTRUCTURES STRUCTURES OF THE STRUCTURES REPORTED THE STRUCTURES OF THE STR



TURAL LOAD LIMITATIONS

ROOF UNE LOAD:
A-128 FOR
ROOF UNE LOAD:
A-25 FOR
ROADING GATEGORY: (9EF ASSET 7-62)

ROOF COMPONENT & CLUCONIC LOAD E.Fr. = ZONE 1 = 49 PSF ZONE 2 = 81.2 PSF ZONE 3 = 121.7 PSF C.C. AND INDENSIT CHIEGOS.

C.C. AND INDESTRIC CHIEGOS.

C.M. T.C. AND INDESTRIC COLL.

WHO SEED. BOOT SHOW LOAD: SO PET MAXIMUM

E.P+ ZONE 4 -SS.1 PST ZONE 5 - 85.6 PST

COCYLID IN Y LOOD HYSYND YETY DOCULED IN Y LOOD HYSYND TO BE STISME FOVE CHIS BULDNO IS NOT DESCRIP FOR FUNCTION OF THE UPPER HALF OF A HILL OR ESCAPPHENT EXCEDING IS FEET IN HOGH. 1/18

(SEE APPENDIX FOR ICE MAKER INFORMATION) ICE HOUSE WATER USAGE CALCULATIONS:

JAMES E. BRADLEY, P.E. CONSULTING ENGINEER 1765 CARNEGE AVENUE CLEARWATER, FL 33756

UNITS WITH 1 OF 2 ICE MAKERS

MODEL 400SM OR 750SM ARCTIC TEMP ICE MAKER

16#x120=1920# OF ICE/DAY @ 56#/FT FOR ICE WATER USAGE BASED ON 120 MAXIMUM VENDS PER DAY & 16# OF ICE EACH

SO STATE OF THE PARTY OF THE PA

=34.29 FT OF ICE/DAY

=34.29 FT \times 0.897 = 30.76 FT OF WATER =30.76 FT \times 0.748 = 230 GALLON/DAY OF WATER

ICE TO WATER CONVERSION 55/62.4 = 0.897 FT OF WATER = 1.0 FT OF ICE DUE TO EXPANSION

ACCESSIBILITY MOITS.

AMANTENANCE IS REQUEST. THE MAINTENANCE REQUIRED SHALL BY DONE ONLY BY FACTORY THANED MECHANICS WHO HAVE THE ABLILITY OLD ERROUND THE MACHINE INTIGHT SPACES TO PERFOM SERVICE.

THE REQUIREMENT FOR AUGUSTN RESTAROWS IN MOTHER BUILDING UP TO 500 FT AWAY IS THE RESPONSIBILITY OF THE LOCAL JURISDICTION.

EEEE OON REEE WAS TOO WAS TOO ON THE TOO ON


MOSVAN STOUNDS ICE HOUSE AMERICA


DATE (STATE OF INDIANA) COVER SHEET M-103 (Plan # 2113-0131) 11-13-08 SCALE: NTS DRAWING NUMBER COVER-1


RECEIVED


MAR 25 2009


INDIANA STATE DEPT. OF HEALTH FOOD PROTECTION PROGRAM




















MODEL M-103, PLAN NUMBER (INDIANA) 2113-0131 ICON DRIBBILE PRESENT SEET SEETO, WEGSRID OF ROLFFESSITY ROLFFESSEYET CREECESTIONERS THE THE THE STATE OF A ROOM STRUCTURE THAT PROTECTS OF THE PROPERTY OF TO THAT ABOUT MAST DEPOSAL TANK TO HAVE SHAT-OFF VALVE SELECTOR FOR EACH SHEEPISH (SEE ON FILT OF FILE). TO ALL PAIRAG AUST AS ABOD BRAVE BUAUTY HOSE SIZES TO BE FROD STADE THE (SEE YORS A ABOUT) is all soldeds. Each advagle, thather spall was a prevention value of the contrast value of the $t_{\rm c}$ A PARTICULAR SERVICE OF TREASED 1-1/A MON OF LINKING MEANING BE SERVICE WITHOUT BY THE AREA OF LINKING MEANING BY LINKING PARTICULAR SERVICE WAS ARRANGED BY LINKING HAND HARMOUND IN A TO BE STOOKED WITH HAND SOME A SHOULD USE STAFFER) TOWERS THE NAMES OF THE WASHE AND MAKE THE PROPERTY OF THE PROPERTY OF THE CONTROL OF THE PROPERTY OF THE ALL ASTRE GROUND CHARANCE AND VENT PRICE WASTI BE STREET SAFT WOLL DECURRED THE TAKE AND THE SERVE SEASON STREET SAFT. WHEN CONNECTED WAS MAD BY BRASS WAS COUNTY OF THE CALVALTES STU-THE THE METERS OF HINDERS SPECTS AS INCOMED BELON-HE AND CALLESSON MATERIAL SPECTS AS INCOMED BELON-HE AND CALLESSON MATERIAL SPECTS AS INCOMED BELON-CONTROL OF CAS CONCESSON TO A COLOR SPECTS AS INCOMED BELON-TONING THE AS AS SENSON TO A COLOR OF CASE OF THE CASE O DAY STORY SALE OF BINGS ASS OF EXCHONS POSSULE WATER OFFWARE THEM THE PEOPLE WATER SYSTEM TO MEET OF ERCECO THE REGUNGUEATS OF ACCOUNTS THAT WATER SPENISHED WATER REQUIRED. ALL DIES NEW HANDS WILL EDWARDS DIES NO HAS DERBISS AN AND HENGEL A WILLIAM DIE NACH ME ROOM THE LOCKING OF CHILD SEE NOW ME HOW THE WILLIAM DIE NACH TON THE TON THE TON THE SEE NOW THE HOND THE ALL PECUACE SHATHOT MALES AND FULL-OFFIC VALVES NOTALLES IN THE WATER STREAMS TO THE WATER STREAMS AND THE PROPERTY ACCESS. BUILDING DRAW AND CLEANQUIS ARE DESIGNED AND SITE INSTALLED BY CIMICAD SUBJECT TO LOCAL LUNGGISTON ASSESSME. NATION SUPPLY LINES SHALL BE POLYBUTNESS, OTHO OR COPPER THE RECORDINGS FAIR SHALL BE INSTRUCED IN ACCORDANCE WITH THE MAINFACTURESS CHARACTURE AND INSTRUCTORIES ALL PARTY THAN SMALL HAT GROW SEALS OF NOT LESS THAN 2" AND NOT HOSE THAN 1" AND NOT HAT STAND SEALS OF NOT LESS THAN 2" AND NOT HAT STAND SEALS OF AND THAN SMALL SEASON ROSTONIAL SHARAID BYT THIVE HORS OR SUALES WILL BE MURLISS ARE A USING ROST OF 114 HER TON FRE SIZES SITS SINGERS WILL FARE IT WHILL SIZES IT I A FRE TON. ANTAN KAMAN KAMINENDARES MEN ANDS BESS, TOLLOSIAN SO DINCH CONSCIPING SALL IN PROTECTION AND ME SALADATION OF AN ANDSSMERS, THE DE PRICEMPLANT PRO MAILON EFCAMEN CONCERNO MET TABLE EGS. 3/8" OF COMMERCIED W/
COMMERCISSON FITTINGS FROM DRIVE TO
IDE MAKER SUMP TANK SECON SESSION NO. 1703 DE MAKER CONCENSES CONCENSES TYP. 1/2" CPVC SCH 40 PIPE INTERNOR REFERCERATION (WATER USED IN ICE WAKING DRINKING MUST BE MUNICIPAL) FROM CHY WATER METER (3/4" TYP.) BACKFLOW PREVENTER MAIN SHUTOFF VALVE MAL PRESSURE REDUCER
FOR CLEANING
FOR CLEANING 9 Save eletess A HOSE BIBB ON SOE WATER TO SHA DELONAL CHAN MACAGE STAG 11-13-08 WATER SUPPLY SYSTEM ICE HOUSE AMERICA STEREO STEREO REVISION CONTROL SCALE. STS JAMES E BRADLEY, P.E. CONSULTING ENGINEER 1765 CARNEGIE AVENUE CLEARWATER, FL 33756 JAMES EI NOV 2 1 2008 DRAWING NUMBER







ICE HOUSE AMERICA

M-103 FRONT AWNING INSTALLATION

REVISION CONTROL

11-13-08	DATE	AWNING	ICE
NTS	SCALE	CONSTRUC	ICE HOUSE AMERICA
C1.0	DRAWING NUMBER	AWNING CONSTRUCTION DETAILS	AMERICA

MODEL M-103. PLAN NUMBER (INDIANA) 2113-0131

WITHOUT WATER DISPENSER

USE MIN. OF 12 BOLTS

8 TOP AND 6 BOTTOM (14" O.C. MAX) FOR SC MPH MINO
LOAD CAPACITY (MITH CANAXS COVERNO)
AND 150 MPH CAPACITY (MITHOUT CANAXS)


WITH WATER DISPENSER

USE MIN OF 20 BOLTS (MITHOUT CANYAS)
LOAD CAPACITY (MITH CANVAS COMPERNO)
LOAD CAPACITY (MITH CANVAS COMPERNO)
AND 150 MPH CAPACITY (MITHOUT CANVAS)
AND 150 MPH CAPACITY (MITHOUT CANVAS)

SNOT GESCHIPTIONS

ELECTRICAL CHART USING 400SM ICE MACHINE

1. — 112V WEATHER PROOF GET OUTLET ON CIRCUIT #25 USED FOR FIELD MOUNTED W.P. LIGHT UNDER
AWMING, 17" FROM TOP OF UNIT
2. — LUNCTION BOX — NEMA 3R MINIMUM
3. — BLONER MOTOR
4. — UTILLTY OUTLET CROUIT #19
5. — LIGHT SWITCH, CIRCUIT #19
6. — LIGHT SWITCH, CIRCUIT #13
7. — MOTOR DISCONNECT SWITCH, NEMA 4 OR EQUAL, 3 POLE, TYPICAL ALL MOTORS
9. — CHAIN 1 MOTOR
10. — FREEZER CONDENSING AND FAN UNIT (ON ROOF)
11. — TOW MOLANDESCENT LIGHT FIXTURE TYPICAL (3) PLACES
12. — (NOT USED)
12. — (NOT USED)
13. — AUGER CONTROL UNIT
14. — 150 AMP (MINIMUM) 3 PHASE SERVICE, NEMA 3R
16. — 2" DIA. DRAIN AT CENTER OF FLOOR TROUGH
17. — CONTROLLER BOX, FABRICATED FROM STAINLESS STEEL TO NEMA 4X STANDARDS



10 H		
Ä		
MOTEL SWALL DWANGES BY MIEROR LAYOUT WHICH TO MIT LETTERS		
R		
20 e32 x		
5 3 3 4		
¥		
3	ĺ	•
3	1	
	1.	

ELECTROAL COMPONENT LOANTON HEE ALLOWINGEE CONSUMPTED SNOWERS IF ANY ELECTRICAL LOADS CHANGE OF ANY STRUCTURAL CHANGES COOM

PROM BREAKER PANEL TO REPROSENATION OFFI

ASCS - 4328A 33: GL 3996 6547385

2448 40,05 Pt (3445

40104 ×E (84 FLDES)

1/3 220 V 3 1.5 14 GA 1/2" 114 GA

3/4 229 V 3/28 14 GA 1/2 14 GA

15 220 V 3 80 3 GA 1-1/c 12 GA

YARES 220 V 318.2 12 CA 1/2" 12 CA

: 20 12 CA

S :: 1: £

30.5

CONCOUR SECUND

3/4 } 220 V 3:28: 14 GA 1/2" 14 GA 220 V 3 1.8 14 OA 1/2" 14 OA

AYSER SERVA

- 45/40 30: 01 38/4-

W.C.F.

NOTE: ALL WAS TO BE ASSUMED STRAWED COPPED THEN OR EQUAL

MODEL M-103, PLAN NUMBER (INDIANA) 2113-0131

90000 2: 90000 2: 90000 2: 90000 2: 90000 2: 90000 2:	Acres In the con-	1	ţa	ţa.		45559	50000	F. Sime?	3000#	souce : 5	CONTROL : :	5	мотояз	10 P	DISC. CR &	150 4W MINN	
		20 1 500			22 320			20 , 300	0.00		1 2200	16450 G	15 (3 (3 (4 (5 (4))))))))))	75 G 5880	# BREAKER SE TH. COADS SE BREAKER CO. & DISC	150 AVP MINMON 36 4 WRE 30 DIR FAMEL	
	35 : spoce	26 : CPE HI,TAPE	34 50000	22 50000	20002	55 Spece	18 3	esson.	12 PEF UNT	15 space	s space	O1	400SW MODE	io E	CP 4 3:50	WATER PROOF NEMA JR	
	5000	350551, O.S	85568	soocs	RECEPT, : S	space	Spece	SIMBIL	22222	2000	CONTROL		NOTORS	Trans	0.50	40,15.	
	27	25	23	23	35	;	:5	į,	;	80	7	5	Li .		CR # 95	VOLIS: 203/240/120 150 AMP MINIMUM 35 4 WIRE	
		20 1 500			20 1 50			20 : 200		F 1	20 1 1200	3	1550	15 3 1550	SREAKER S PH. LOADS BE SAEAKER OR & DISC.	30 CIR.	
									15			1929 3 80	J 30	5- 85	C SE SREAKE	150A MAIN BKR	
,	29	 61	ž	22	20	ä.	ō	 ;;		ö	Ųυ	cr,	<u>,</u>	tsi	R OR #		
2000	22000	Sevile led	şpace	space	space	space	spece	space	REF. UNIT	space	space		TARRA MODEL	E E	DISC.	WATER PROOF NEWA 3R	

MONANA TOTALE GIPT OST SECRETS Y SECULOSOS, NO POST CONTROL TO A SECULO WAS TO A SECULO WAS TO SECUL

OPOLACY TYPELARTER SOMEONIES WITH ALASTO COLER CROCKIT WAVES THE BEANACTY AS LATED HERE PROVIDE BUGRAVED WAVEFALME ON TAIL TO PANEL

TOPE CARE AREA

TOTAL CRECISION DATE:

- 19482 (1918) 1818 - 1918 - 1

PROVIDE TYPEWRITEM SCHEDUE TO SE EXACTLY AS LISTED HE FACE OF HAMEL

	į	823
		812 PC
	1	ĈΩ
o N		
REVISION CONTROL	A EN	
STAGO	NOV 2	
Ž	1:	ES.
	2008	\$#
		•
	معمور البالم المراه المالية	

	Manage Comment	SCHOOL S POSSESSINGS		
	<u> </u>	0	Ş	
		Š	3rr¢	ą
-			ROGEROS	REVISION CONTROL
		60	9	

ICE HOUSE AMERICA


DATE ELECTRICAL SYSTEM M-103 SCALE DRAWING NUMBER:


11-13-08 2 $\vec{\omega}$

ELECTRICAL CHART USING 7005M ICE MACHINE

ELECTRICAL CHART USING 7005M ICE MACHINE

ELECTRICAL CHART USING 7005M ICE MACHINE The state of the s





Ryerson Tull So. Ga. Elect Liting Universal So. Ga. Elect PACKAGED CONTROL PANELS
PACKAGED CONTROLS TO BE FACTORY FABRICATED IN ACCORDANCE WITH APPLICABLE UI. STANDARDS, USING UI.-LABELLED COMPONENTS. COMPONENTS TO BE APPLIED IN ACCORDANCE WITH UI. TESTING AND LISTING CRITERIA. Pushbutton Switch (Stack)
Pushbutton Switch (Stack)
Pushbutton Switch (Stack)
Pushbutton Switch (Stack)
Pushbutton Switch (White)
Streaker 204 3Pde
Pour Block
Pour Block
Pour Block
Pour Block
Back Pour Block
Cont Block
Cont Block
Cont Record
Cont Recur Assamply
Cont Recur Bezel
Cont Pour Block
Cont Recur Bezel
Cont Pour Block
Cont Recur Bezel
Cont Pour Block
Cont Contactor
Overload 400
Overload 270
Overload 270
On Rail
Sizy Terminal Block
Breaker 20A 1Pole
Ground Terminal Block
Fuse Holder 4A Reset 8967 Realer Motor Starters Bulk Selectors 7 Display nitol Relays Coln Mach-

MODEL M-103, PLAN NUMBER (INDIANA) 2113-0131

CONTROL PANEL COMPONENT DETAIL M-103


ICE HOUSE AMERICA

REVISION CONTROL

11-13-08

SCALE:

DRAWING NUMBER









Component List

Credit

20

JAMES E BRADLEY, P.E. CONSULTING ENGINEER 1765 CARNEGE AVENUE CLEARWATER, FL 33756





2008 INDIANA ELECTRICAL CODE MATERIAL SPECIFICATIONS

All equipment will be listed by Ut. for the application for which it is used — all equipment will be installed in accordance with the listing.

All receptacles handled on 120 volt circuits will be rated at 125 volts (AC), single phase, 2 pole, 3 wire. All receptacles installed on 120-240 volt circuits will be rated at 125/250 volt circuits will be rated at 125/250 volts (AC), single phase, 3 pole, 4 wire.
Receptacles installed on 120-240 volt circuits will be provided to the grounding type. All receptacles installed on 15 amp and 20 amp branch circuits will be of the grounding type. All receptacles will be installed only on circuits by which their current and voltage rating careful and the provided of the grounding type. All receptacles will be installed only on circuits by which their current and voltage rating careful and the provided of the provided of the grounding type. All receptacles will be provided only by rating the provided only only the provided only interrupted provided only only the provided only only the provided only interrupted provided only only the provided only the provided only only the pro

Service entrance will be by overhead system and will be indicated on-site (subject to local inspection).

lice entrance coals conductors will be insulated by extruded thermodiastic or inormosetting insulating material. Rigid motel conduit Service entrance coales Type MC coals The service entrance will be installed by any of the following methods

ENGINEE ENIMALE EN STATE OF ST

Service entrance conductors must be sized to carry the current computed in the electrical load calculations. The conductor capacity will be determined from tables 310.05 through 310.19 in the NEC

ø The grounded service conductor will not be smaller than the grounding electrade conductor minimum size specified in Table 250.56 in the NEC. The grounding electrons conductor will also be sized from Taple 250.66

Service apples with be equipped with a rain tight service bead

Every building will be provided with only one service grop

. Disconnessing means will be provided in each service panel to disconnect all conductors in the building from the service entrance conductors

The service paner and each service disconnecting means (switches or manual circuit breakers for ungrounded conductors; ground but with pressure connectors for grounded announcer) with the listed of or use as service equipment. The service panel wit be sized to decommodate all of the building's bronch circuits and service conductors by compared in the electrical cod colluctions. The service disconnecting means will consist of not more than 8 switches or manual circuit breakers mounted in the single service data annual. The survive disconnecting means can be installed either instat or outside of the building of a readily accessible location nearest the paint of entrance of the service enfrance conductors.

Service conductors will be connected to the vervice disconnecting means by pressure connectors or clamps. Soon disconnecting means (switches or manual circuit breakers) wit simultaneously disconnect of underground conductors. All service disconnecting greens will have a rating not less than the face to be parried as computed in the electrical load calculations. Service disconnecting equipment installed outside of the building will be listed for use m^2/b artiseaton

All installations of electrical maters will be performed on-site and will be subject to land inspection. All maters will be provided by others

All equipment intended to break current at foult levelo (i.e., circuit breakers) will have an interrupting expacity sufficient for the voltage and the aurrent available at the line terminate

All stacks oreasers wit have an interrupting rating of 5,000 amos. All street treater trip points (time required to contact) wit be suitable for the intended application.

40 panel boards will have phase and voltage ratings as specified on approved biong. All panel boards will have a current rating not less than the feeder requirements computed in the electrical rapid colouiditions.

ú service equipment will be provided with a main bending jumber or equivalent installed to connect the supply side of the grounded service conductor to the bond board frame. The bonding jumper will not be smoller than the sizes ligated in Table 250.55.04 the NEC

A grounding consection will not be made to any grounded directl conductor on the load side of the service disconnecting means All service entitines will be growness — the grounding discribede conductor will be connected to the grownesd service conductor of any accessible point from the load end of the service draw to and including the bus to which the grounded service conductor (neutros) is connected.

ş:51

All single phase. 3 wite branch alcalite will have the grounding announcer boated to the grounded service tolerwing grounding will be bettermed by using clomps or pressure connectors.

Noted transparts for service connectors and branch circuits.

Exposos non-current-partying metal parts of equipment connected by parmonent (fixed) witing methods without parts of grounding-type featpticoles. conductor and the grounding electrops canadator at the panel unless otherwise indicated on the electrical

threaded aduatings, banding jumbers, banding-type locknuts or bushings in the tollowing obsess

which may become electrically energized

000000

Esnaing to maintain electrical continuity will be provided between non-ecutrant-corrying match parts by using planned, pressure abtrinactors, burnior calciment including mater fittings, pases, etc.

Survive receivages a service code armor or sheeth continuity of material content or atmost receivage a grounding electrode conductor white survive continuity of grounding electrode conductor white survive and other non-current-corrying metal is branch of cuts.

Metal taceways, back armor, enclosures, frames, fittings and other metal non-current-corrying parts that serve as grounding conductors.

interior metal pising, metal oir ducts, and motal frames, if any, will be banded to the service entrance enclosure grounded conductor or the service or grounding electrode conductor

122 The service artrance grounding electrode system will be installed an-site by others and will be existent to local inspection

Equipment grounding conductors can be ony of the following:

Single sopper wite, solid or stranded, insulated, covered or bare Capper wire enabled in a capte Rigic nexts (contained).
Electrical metallic tubing

Equipment grounding conductors will be installed using only fitting for joints and terminations which are listed for the specific apolisation.

REVISION CONTROL

DATE 11-13-08 ELECTRICAL NOTE#1 ICE HOUSE AMERICA NTS DRAWING NUMBER E1 7

MODEL M-103 PLAN NUMBER (INDIANA) 2113-0131

Equipment grounding conductors will be sized in accordance with Table 250.122 in the INDIANA ELECTRICAL CODE

JAMES E. BRADLEY, P.E. COMSULTING ENGINEER 1765 CARNEGIE AVENUE CLEARWATER, FL 33756

A box or fitting will be installed at each condustor splice connection point, autlet, switch point, junction point or pull point for the connection of the condust, electrical medical tubing or other receivance.

21.

22.

iy io

2

25

26

ž All conductors will be insulated and be copper. When installed in receivery, conductors or rize No. 3 and larger will be stranded.

Recent directive, except as indicated below and/or unless otherwise specified on the electrical plan, will consist of Type AC capie will, not be used as service entrance cable.

All penel board directis shell be legibly identified as to purpose of use on a circuit directory located on the electrical plan, will one in accordance with the satisfament candult will not be smaller than ½" electrical trade size. The number of conductors in the sizual will not exceed the personal or straight of Chapter 9 of the NEC.

Reside metallic tubing will not be smaller than ½" electrical trade size. The number of conductors in the straight materials or protected from correction by since or conductors in the straight metal conduct. Will not be smaller than ½" or larger than 4" electrical trade size. The number of conductors in the straight metal conduct. Will not exceed the personal size of through 5 of Chapter 9 of the NEC.

Personal including will not be smaller than 5" or larger than 4" electrical trade size. The number of conductors in the straight metal conduct. Will not exceed the personal of the personal of

27. Electrisis metallic tubing will not be smaller than "K" or larger than 4" electrisat trade size. The number of conductors in the tubing will not exceed the percentage fill specified in Tobies 1 through 5 of Chapter 9 of the NEC.

All supports, costs, straps, etc. will be of corresion-resistant moterials or protested from corresion by the or codmium. Couplings and connectors used with EMT will be the universed type and will be listed for their intended application.

When a listing requires nigher temperature rated wring

WHITH EVERY

Conductors used in conduit for other than the service entrance will be Type T or TW (80 agrees C wine) unless higher temperature rated insulation is required by a specific explanent, wire specified the listing will be installed to graduate and the service specified to the listing will be installed to conductors in any box will not exceed the number listed in Table 314.15(a) and/or Table 314.15(b) of the NEC. All boxes will be All boxes will be listed for their intended application.

Al such devices will be rated at 500 volts and have a current rating not higher than the rated ampacity of the circuit व्यवस्थि

32. All seitenes and circuits brackets will be listed for interiority depotes to the requiring apecto switches or over-current protection in accordance with Circuit process used as seitendes in 120 and flavoratoral ligning circuits will be listed for such switching outly one will be marked SAD.

33. All carbuit process for branch effects will be the market type. Brown ordains will be provided with over-current protection (circuit produces) with will open all ungrounded conductor of the circuit.

From ordains will be settleded to a one in board mounted in a welfield position.

All branch ordains and over-courrent protection will be dited as specified on the approved electrical plans. *;* listing will be provided 8 the required switches or over-ourrent protection.

Ļa jās All equipment intended to break ourrent at other than four lawds (i.e., switches) will have an interrupting according rates as the aircuit valvage equal to an exceeding the current that must be interrupted - see below

a.C. Roard Carefol Use Stop Switches:
a. Used only on AC circuits is including incondescrent lamp loads, and fluorescent a. Resistive and including incondescrent and fluorescent a. Water loads (full-land current for motors rated at 2 HP or less) will not proseed a. Water loads (full-land current for motors rated at 2 HP or less) will not proseed lamp loads, will not exceed the ourrent roting of switch at the voltage involved 180 % of the ourrent rating of the switch at its rated voltage

40 - 80 Actes Caneral Use Snop Switches of the switch at the voltage involved-switches used to control insurangement term paged will be "" roted.

Bestrictive Leads will not exceed the outrent rating of the switch at the voltage involved-switches used to control insurangement term paged will be a "" roted.

But a switch income (Numericent Terms loads and full-blood outrent loads for motors rated as 2 HP or large) will not exceed \$87 or the outrent rating of the switch at the applied voltage. Switches rated in horsepower can be used to control motors within their rating at the voltage applied. All such controllers will have an interrupting appaalty equal

Visite: Controllers:

Visite: Controllers:

Wishights at particular and stop motors, except as indicated above for AC rated and AC ~ DC rated switches, will have a norsepower rating not lower than the horsepower rating of the motor.

If you provided in the scalesc—rate current of the motor.

Exemption: Sectionary motors rated at 1/8 HP or less provided with thermal evertocal protection can use a bronch provided time careful areover as the controller.

Exemption: Sectionary motors rated at 1/8 HP or less provided with thermal evertocal protection can use a bronch provided indicates that the controller.

Exemption: Sectionary motors rated at 1/8 HP or less provided with the boilest. 35. East expendence entrance conductor will be envoled with over-current protection or circuit breakers. All such circuit breakers will have a rothig not higher than the allowable amountly of the conductor.
All such circuit process must be listed as parked expense entirens over-current protection will be found to the blank or as protection of the such circuit protection will be found for the short-circuit current collable as its supply cerebicals. over-current protection and disconnecting means.)

Over-earriert devices will be enclosed in achinats which are mounted in a vertical obsition. Enclosures for over-earriert devices in damp or wet copplians will be listed and identified for use in such locations.

Eventified Specifications listed on approved plans may pre-embt the specifications stated breach exacts of electrics companients and installations and companients and installations and companients.

Where more from one nomined voltage system exists in a publicity, seek underground system, conductor (of a matrix proper strain) seek to be benefited by phase and system. The means of identification shall be permanently posted at each branch-diract panel board.

Where a main banding jumper is a screw, the screw chall be identified with a green finish that bhail be visible with the screw installed

Plugminmype circuit breakers that are book foo shall be setured in place by an additional fasturier that requires other than a pull to recose the device from the mounting means on the basel

ICE HOUSE AMERICA ELECTRICAL NOTES #2 REVISION CONTROL MOULTRIE, GA

25 11-13-08

SOALE

DRAWING NUMBER

XIS

MODEL M-103, PLAN MUMBER (INDIANA) 2113-0131